
LABRepCo
An Employee-Owned Company

How to Measure for a Cart/Bottle Basket Cover



The diagram above shows what we consider as the Length, Width (depth), and Height.

Height:

- If the cart has wheels – Measure from the top of the wheels to the highest point of the cart. Please be sure to include anything that you would store on top of the cart (ex: if you have a basket you keep on top).
- If the cart does not have wheels – Measure from the floor to the highest point of the cart. Please be sure to include anything that you would store on top of the cart (ex: if you have a basket you keep on top).

Length & Width:

- Measure both of these dimensions at the widest point.

Please provide us with the **exact** measurements, no approximations or extra allowances.

Openings:

- On the front of the cart (where the length is measured) there are 2 cuts on the front, one at each corner from the bottom to the top, so that you can flip the flap up to access what you are covering.

101 Witmer Road, Suite 700 • Horsham, PA 19044 • Phone 1-800-521-0754 • Fax 215-442-9202
www.labrepco.com • sales@labrepco.com